

ENOC CRYOGEN N

PRODUCT DESCRIPTION

ENOC Cryogen N refrigeration oils are manufactured from premium quality narrow cut naphthenic base stocks, dewaxed to very low wax content. Consequently they have very low pour points and good miscibility with Freon to provide low Freon floc points with CFC refrigerants such as R-12. **Cryogen N** oils can contribute towards prolonged compressor and seal life through the high thermal stability which controls the formation of carbon and gummy deposits at elevated temperatures that are encountered in the high pressure side of the refrigeration cycle.

APPLICATIONS

- ◆ Industrial refrigeration equipment
- ◆ Business/domestic and office air conditioning systems
- ◆ Reciprocating and rotary refrigeration compressors
- ◆ Refrigeration systems using freon (CFCs), ammonia, carbon dioxide

Not suitable for systems containing HFC refrigerants ie. HFC 134a

RECOMMENDATIONS

BS 2626-1992
Carrier, PP46-1

Not recommended for use in compressors for air breathing equipment.

BENEFITS

Cryogen N provides:

- ◆ Reduced downtime by maintaining clean working surfaces
- ◆ Prevention of waxy and gummy deposits through high oil thermal stability
- ◆ Very good miscibility with refrigerants for good lubrication
- ◆ Extended oil service life, excellent resistance to oxidation
- ◆ Low pour and floc points and miscibility with refrigerants

Technical Data*			
ISO VG	32	46	68
Kinematic Viscosity @ 40°C, cSt	30 – 34	44 – 48	65 – 71
Flash Point, COC, °C, min	204	216	238
Pour Point, °C, max	-42	-39	-36
600A Refrigerant Floc Point, °C	<-60	<-55	<-50
Product Code	244001	244002	244003

*The information prepared provides the typical properties that are considered as representative. Some variation which will not affect performance is possible

HEALTH AND SAFETY, ENVIRONMENT

The information on this product is available in the ENOC Material Safety Data Sheet (MSDS) as a guide to the precautions and safe handling of this product and its disposal. For further information we recommend you review the MSDS. Handled correctly there are no special precautions suggested.